Software for PN-Y556/Y496/Y436/Y326

SHARP Content Distributor for FlashAir™

Don't you have a problems about signage when using USB media player?

Cannot reach the monitor installed in high place

Monitors are installed in the wall; USB interface is hidden

USB memory might be prohibited to use in the office

SHARP Content Distributor for FlashAir

Wirelessly overwrite the contents saved in FlashAir. Problems will be solved!

FlashAir･･･SD card with a wireless LAN function

High Place

Hard to reach place

Restaurant

Housing / Chassis

USB terminal is hidden

Retail Shop

Office Signage

USB memory device might be prohibited to use

Office

What is SHARP Content Distributor for FlashAir?

This is a software to allow you to distribute contents as well as overwrite the contents saved in the FlashAir all via wireless LAN.

STEP1

Insert a pre-set FlashAir

STEP2

Create / Distribute content list

Distributed

On / Off power of monitor

Features

Easy Distribution via Wireless LAN

- Workable in places **where it is hard to insert / remove a media**; such as in high place, in housing /chassis.
- **No need for cables**

Easy Installation

- **Just prepare FlashAir**, then you can start signage.
- Overwrite the contents from PC, smartphone, etc..

Simple Operation

- **Simple operation screen** allows you to create content lists intuitively.

Operation Flow

[Requirements] LCD monitor (PN-Y556/Y496/Y436/Y326), FlashAir*1, Device*2, Contents to be played (still image(jpg), video (wmv))
[Monitor Settings] Set "NO SIGNAL AUTO INPUT SELECT" to "ON" in SETUP menu. Set "POWER SAVE MODE" to "ON" in SETUP menu. These settings allow you to update the contents by a remote control.

*1 Toshiba FlashAir™ equipped with the requisite Sharp HTML application. Not compatible with FlashAir W-02 or earlier versions. Please consult with your local authorised Sharp dealer or representative regarding availability of the SD card. *2 Computer, tablet, or smartphone for use of SHARP Content Distributor for FlashAir.

①Download / Setting

- Download the SHARP Content Distributor for FlashAir*3 application .
- Launch the software and configure required settings for the FlashAir.

*3 Please consult with your local authorised Sharp dealer or representative regarding availability of the application.

②Connect to FlashAir

- Insert a FlashAir into the monitor, then turn "ON" the monitor.
- In the wireless settings of the device that you will use to add content, connect to the FlashAir.

③Distribute Content

- Open the browser and connect to the URL below.

SHARP Content Distributor for FlashAir page : http://flashair/

- Add / Delete content, set order of the contents to be played.

Distributed

- Using remote control, turn "ON" the monitor.
- The contents will start to be displayed.

SHARP

FlashAir is a trademark of Toshiba Corporation. All other brand and products names may be trademarks of their respective owners. All screen images appearing this material are simulated. Design and specifications are subject to change without prior notice.