SHARP®

SHARP Content Distributor for FlashAir
Setup tool Operation Manual

Introduction

To use SHARP Content Distributor for FlashAir, an application must be added to FlashAir using this software.

Glossary

- This manual explains how to use SHARP Content Distributor for FlashAir Setup tool.
- The following terms are used in this manual.

Device	Computer, tablet, or smartphone for use of SHARP Content Distributor for FlashAir.
Panel	LCD Monitor
Content (files)	A video or image file to be displayed or played on a panel. Please prepare content files yourself. Only the content stored in terminals can be used.

1. Applicable models (as of December 2016)

OS	Windows 7 (32-bit or 64-bit version), Windows 8.1 (32-bit or 64-bit version), Windows 10 (32-bit or 64-bit version)
Memory	At least 2 GB
Monitor	1280 ×1024 dots or higher
FlashAir	Toshiba W-03

*Please use a computer that is equipped with wireless LAN.

*Please use computer with built in SD Card reader or attach external SD reader.

2. Preparations

1) If your FlashAir is not factory default settings, you must format FlashAir by using your computer's format function , and then use the "FlashAir Software Update tool" to update the software. You can download the "FlashAir Software Update tool" from the following website provided by Toshiba Corporation:
https://www.toshiba.co.jp/p-media/english/download/wl/updatetool_w03.htm
2) Begin by extracting "SetupTool_Cdist-forF_x.x.x.x.zip" to any folder. Insert FlashAir in your computer, and run the Setup Tool (Cdist-SetupTool.exe).

3. Procedure

1) Insert FlashAir in the computer or into the SD card reader.
2) Select the FlashAir drive letter to be set up.
   - If FlashAir does not appear, re-execute the Setup Tool.

3) Setup wireless LAN on FlashAir.

- The default SSID is [FlashAirSharp]. You can set the SSID using 1 to 32 alphanumeric characters.
- The default password is [12341234]. You can set the password using 8 to 64 alphanumeric characters.
- You can select [Wireless LAN auto stop time] from among of “Do not stop” (default),5,10 and 30 minutes. If devices do not connect to FlashAir within the specified time-out period, wireless LAN is automatically disconnected.

4) After Setup is selected in SSID configuration, setting up activity screen will appear. Once complete, remove FlashAir from your computer and then reinsert.

- In some cases, it may be necessary to remove and insert FlashAir twice.

5) Check the connection to FlashAir.

- Insert FlashAir in your panel, and confirm panel is turned ON.
- In the wireless settings of the device that you will use to add content, connect to the SD card SSID.

  ※The connection in this case does not have an Internet access.

  ※If you are using Android, a message to confirm network connection may be displayed. In that case, please keep the current connection.

- Enter to the following address into your browser. http://flashair/
- Make sure that the SHARP Content Distributor for FlashAir page appears.

4. Caution

- To use this software, .Net Framework4.5.1 is needed.
- If FlashAir stops running, you have to reset it to factory default settings and add setup tool to FlashAir. Please operate the procedure Section2. Preparations, (1).
- If wireless LAN disconnects, turn the panel power off and then on. If [POWER SAVE MODE] is set to [ON] in the panel settings, you can also restart with the remote control.

5. Trademarks

- Microsoft, Windows and .Net Framework are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- FlashAir is a trademark of Toshiba Corporation.
- The trademark, Android, is used under license from Google Inc.

SHARP®

SHARP CORPORATION

M EN17D(2)